

USER MANUAL



ELECTRIC HEATER

SY-CL45

WELCOME

Dear Customer,


Welcome to Sytech! Thank you for purchasing the Electric Heater SY-CL45. Please read this manual carefully before operating your product and pay close attention to the precautions which are mentioned below. Store this user manual in a safe place for future reference. We are sure that this new Electric Heater will satisfy your needs.

IMPORTANT SAFEGUARDS

When using any electrical appliance basic precautions should be followed. Please read the following instructions carefully:

1. Make sure the power supply used corresponds to the rating label.
2. Never obstruct or block any openings of the heater.
3. Use the heater only on a flat surface.
4. Always disconnect the appliance from the main power supply when not in use and when cleaning.
5. Do not leave the heater unattended when in use.
6. Never cover the heater as this may lead to the risk of fire.
7. Keep the appliance at a distance of at least 90 cm from any flammable material such as furniture, curtains, bedding, clothes or papers.
8. Do not use this heater in the immediate surrounding of a bath, a shower or a swimming pool.
9. Do not immerse the heater in water or allow for water to come into contact with the plug or control device.
10. Keep this heater clean. Do not allow objects to enter the ventilation opening as this may cause electric shock, fire or damage to the heater.
11. Close supervision is required when any appliance is used near children.
12. Never allow the cord to touch wet or hot surfaces, become twisted or be within the reach of children.
13. Do not use outdoors
14. Do not place on or near a hot gas electric burner.
15. If the supply cord is damaged, it must be replaced the manufacture or its service agent or a similarly qualified person must replace it in order to avoid a hazard.
16. Do not use the appliance for other than its intended use as described in this instruction book.
17. Do not place the heater immediately below a socket outlet.
18. This appliance is intended for household use only.
19. Do not leave the heater on overnight.
20. While cleaning, make sure not to use a wet cloth or use water on any part of the unit, as this may cause a short circuit or electrical shock.
21. Do not use this unit in any area where water present.
22. Make sure the power cord is placed at the back away from the front panel of the heater.

PARTS OF THE SY-CL45



HOW TO OPERATE

1. Remove the unit from the box and take off any protective wrapping.
2. Place the heater on a smooth level surface and least 30cm away from any obstacles.
3. Plug your fan heater into the power supply. Make sure your power supply corresponds to the power indicated on the rating label.
4. Heat temperature setting can be regulated using the switch located on the top of the heater (switch 2). To turn the appliance on:
 - * Fan - for a lower power air circulator; turn the dial on the right clockwise once for the fan function
 - * Low - Turn it twice for Medium heat setting (1000W). This setting is best suited for smaller, well-insulated areas that require less warming.
 - * High - Turn the switch once more for High heat setting, (full power 2000W). This setting is best suited for larger spaces as it heats up quickly. .
5. To set the temperature level, move the thermostat control (switch 1) to the desired level.

OVERHEATING SAFETY DEVICE

Your heater is fitted with a safety device that switches off the heater in the event of overheating.

Should the heater stop working, turn the heater off and inspect for any blockage of the inlet or outlet. Wait at least 5 minutes before attempting to restart the heater.

If the heater fails to operate, the safety device will switch the heater off again. In this case please contact Sytech Service Center for further assistance.

CLEANING YOUR FAN HEATER

1. Always disconnect the appliance from the main supply before cleaning.
2. Clean the outside of the heater using a damp cloth and dust the inside with a dry cloth as well.
3. Do not use any detergents/solvents or chemical agents to clean the heater.

NOTE: If the power supply cord or plug is damaged, immediately stop the use of the appliance and contact Sytech Service center for further assistance.

SPECIFICATIONS

Electric Heater

Adjustable heating power

Ideal for 15-20 m² spaces

3 position settings: Cold air (fan), Moderate, Hot

Adjustable thermostat

Power On indicator

Overheat protection

Totally portable

Power: 1000/2000 W

RPM: 2300-2500

Weight: 1.0 kg

Dimensions: 235x140x267

DECLARATION OF CONFORMITY

Manufacturer Name: Satyatrade S. L.

Address: Pol.Ind.La Raya. C/ Guadalquivir, 2.

Camarma de Esteruelas, 28816 Madrid

Tel: 902 430 967

Fax: 91 8864285

NIF: B83254763

Manufacturing country: China

Sytech® SY-CL45 complies with the following directives:

EMC Standard: Directive 2004/108 CE

LVD Standard: Directive 2006/95/CE

ROHS Standard: 2011/65/EU Restriction of Hazardous Substances

Signed: Ajeet Nebhwani Utamchandani

Sole Administrator

